


## **AX1699**

HVA 701 Enduro / SM Adventure Skid Plate BLUE









3 NE01-02-003 - TFHC 6x25mm

4 NE01-02-004 - TFHC 6x30mm

1 NE01-06-028 - TH 6x35mm

2 NE01-11-001 - Special screw

8 NE01-03-001 - M6 Washers

1 NE01-03-006 - M6 LARGE Waher

8 NE01-04-003 - EM6F


1 PM01-10-019 - 30mm thick block

1 PM01-04-261 - 20mm thick block

1 PM01-04-262 - 20mm thick block

1 PM01-06-075 - 8mm thick plate

1 NE04-01-240 - Blue sticker



The paper instructions may be limitless, a tutorial video is available to help



























A skid plate is made to protect the vital components of your bike and does not have a « life warranty » . However, production default may happen and we cover it during the first year of use.

In case of premature breakage, please write to: contact@axpracing.com