

# ANBAUANLEITUNG

mounting instructions • instructions de montage • instrucciones de montaje • istruzioni di montaggio

## KFT.22.114.65001/B

beinhaltet • contains • contient • contiene • contiene

KFT.22.114.30000/B

KFT.00.152.36000

HSK.00.745.10001/B

LOC.00.745.10200

Art.-Nr. / Item No.: KFT.22.114.30000/B

Revision: 00 · Datum / Date: 02 - 2020

## PRO Seitenträger

## PRO side carriers

**DEUTSCH** - Vielen Dank, dass Sie sich für dieses Premium-Produkt von SW-MOTECH entschieden haben. Bitte besuchen Sie unseren Webshop für weitere Informationen wie Modellzuweisungen und PDF-Anbauanleitung. Erforderliche Dokumente (z. B. ABE) stehen als Download zur Verfügung.

Die Montage und/oder Wartung dieses Produkts erfordert ein gutes technisches Verständnis! Zu Ihrer eigenen Sicherheit empfiehlt SW-MOTECH, die Montage und/oder Wartung durch eine Fachwerkstatt durchführen zu lassen! SW-MOTECH übernimmt keine Haftung für Schäden, die durch eine unsachgemäße Montage und/oder Wartung verursacht wurden!

Beachten Sie alle in der Anbauanleitung angegebenen Hinweise und die für die Montage relevanten Informationen im Fahrzeughandbuch. Nichtbeachtung kann zu Schäden am Fahrzeug bzw. zur Gefährdung des Fahrers führen! Diese Anbauanleitung ist nach unserem derzeitigen Kenntnisstand verfasst worden. Rechtliche Ansprüche auf Richtigkeit bestehen nicht.

Dieses Produkt wurde für Fahrzeuge im Werkzustand entwickelt. Die Kompatibilität mit Original-Zubehörteilen bzw. den Zubehörteilen anderer Hersteller kann nicht gewährleistet werden. Stellen Sie des Weiteren VOR Montage dieses Produkts sicher, dass sich alle beweglichen Teile (z. B. die Kette) im ursprünglichen Wartungszustand befinden. Montiertes Zubehör kann das Fahrverhalten und/oder die Stabilität Ihres Fahrzeugs verändern.

## ALLGEMEINE HINWEISE

Beachten Sie die landesspezifischen Vorschriften für Zulassung/Betrieb Ihres Fahrzeugs bzw. anwendbare TÜV-Vorschriften. Lassen Sie eintragungspflichtige Teile nach Montage durch Ihre Prüfstelle in die Fahrzeugpapiere eintragen.

**VORBEREITUNG:** Lesen Sie die Anbauanleitung aufmerksam und stellen Sie sicher, dass alle Teile der Stückliste vorhanden sind. Achten Sie darauf, dass Ihr Fahrzeug sicher steht und nicht umfallen kann. Schalten Sie den Motor ab und ziehen Sie den Zündschlüssel. Lassen Sie ggf. den Motor/Auspuff abkühlen. Klemmen Sie bei Arbeiten an der Elektrik die Fahrzeugbatterie ab. Verwenden Sie geeignetes Werkzeug. Lassen Sie sich von einer zweiten Person helfen.

**MONTAGE:** Alle vom Motorrad gelösten Teile und Verbindungen sind gemäß den Fahrzeugherstellangaben wieder zu montieren oder durch die von SW-MOTECH gelieferten Teile zu ersetzen. Sichern Sie, falls nicht anderweitig definiert, alle Gewinde mit mittelfester, flüssiger Schraubensicherung.

**Alle nicht durch SW-MOTECH definierten Anzugsmoment-Vorgaben müssen beim Fahrzeughersteller oder einer Fachwerkstatt erfragt werden!**

**FUNKTIONSKONTROLLE:** Stellen Sie nach der Montage sicher, dass alle zuvor gelösten Teile und Verbindungen wieder ordnungsgemäß montiert wurden. Achten Sie außerdem auf die uneingeschränkte Freigängigkeit und einwandfreie Funktion sämtlicher Fahrzeugteile. Kabel, Züge und Schläuche dürfen nicht scheuern und/oder geklemmt werden. Führen Sie vor Fahrtbeginn eine umfassende Funktionskontrolle durch. Überprüfen Sie nach den ersten 50 km und anschließend in regelmäßigen Abständen das Anzugsmoment aller Schraubverbindungen und den ordnungsgemäßen Sitz des Produkts.

## PRODUKTSPEZIFISCHE HINWEISE

| Maximale Zuladung                                                                                         | Höchstgeschwindigkeit                                                                                 |
|-----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|
|  10 KG (22 lbs) /Seite |  130 km/h (80 mph) |

**ACHTUNG:** Die angegebene maximale Zuladung beinhaltet das Gewicht von Koffer/Gepäck und Adapterkit! Es gilt die vom Fahrzeughersteller genannte, maximale Zuladung des Fahrzeugs!

Die Seitenträger wurden ausschließlich für die Verwendung von SW-MOTECH Adapterkits konzipiert.

Demontieren Sie die Seitenträger bei Fahrten ohne Gepäck. Benutzen Sie die Seitenträger immer paarweise.

**ACHTUNG:** Achten Sie darauf, dass sich die Koffer nach Montage am Fahrzeug nicht im Abgasstrom befinden! Verbrennungsgefahr!

**ENGLISH** - Thank you for choosing this premium product from SW-MOTECH. Please visit our webshop for additional information, such as application charts and PDF mounting instructions. Any other documents that may be required (e.g. ABE certifications), are also available for download at our webshop.

Installation and/or maintenance of this product require good technical understanding! For your own safety SW-MOTECH recommends having installation and/or servicing carried out by a specialist workshop! SW-MOTECH assumes no liability for damage caused by improper installation and/or maintenance work!

Carefully follow all the directions given in the mounting instructions and pay attention to all relevant information in the vehicle manual during assembly. Nonconformance can lead to vehicle damage or even endanger the driver! These mounting instructions are written based on our current state of knowledge. Legal requirements for accuracy do not exist.

This product was developed for vehicles in their factory setting. Compatibility with original accessory parts or other manufacturers' accessory parts is not guaranteed. Furthermore, BEFORE installing this product, make sure that all moving parts (e.g. the chain) are in the original state of maintenance. Installed accessories can change the driving behaviour and/or stability of your vehicle.

## GENERAL INFORMATION

Observe the country-specific regulations concerning vehicle registration/operation as well as TÜV regulations if applicable. If required, register installed parts in the vehicle documents through an appropriate inspection authority.

**PREPARATION:** Read the mounting instructions carefully and make sure that all items of the parts list are included. Make sure that your vehicle is parked safely and cannot fall over. Turn off the engine and remove the ignition key. Let the motor/exhaust cool off if necessary. Disconnect the vehicle battery when working on the electrical system. Use appropriate tools. Have another person to help you.

**MOUNTING:** All parts and connections removed from the vehicle must be reinstalled in accordance with the vehicle manufacturers' specifications or replaced by parts delivered by SW-MOTECH. Secure all threads, unless otherwise specified, with medium-strength liquid thread locker.

**Torque specifications undefined by SW-MOTECH must be obtained from the vehicle manufacturer or by a specialist workshop!**

**FUNCTION CHECK:** After installation make sure that all parts and connections previously removed are properly replaced. Also make sure that no moving parts are obstructed and no function of the vehicle is hindered in any way. Cables and hoses must not rub and/or be pinched. Before starting to ride, perform a comprehensive check of all functions. After the first 50 km and then at regular intervals, check the tightening torque of all screw connections and the proper fit of the product.

## PRODUCT SPECIFIC INFORMATION

| Maximum Load                                                                                             | Maximum Speed                                                                                           |
|----------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
|  10 KG (22 lbs) /side |  130 km/h (80 mph) |

**ATTENTION:** The indicated maximum load is inclusive the weight of case/luggage and adapter kit! The maximum vehicle load specified by the manufacturer must not be exceeded!

The side carriers are designed exclusively for the use of SW-MOTECH adapter kits.

Dismount the side carriers when travelling without cases/luggage. Always use the side carriers in pairs.

**ATTENTION:** Make sure that after attaching the luggage to the vehicle it is not in the exhaust flow! Dangers of burns!

Konfektionierung durch / Packed by:

Datum der Konfektionierung / Date of packaging:



SW-MOTECH GmbH &amp; Co. KG

Ernteweg 8/10  
35282 Rauschenberg  
Germany

Tel. / phone + 49 (0)6425 / 8168 - 050

Fax / fax + 49 (0)6425 / 8168 - 10


info@sw-motech.com  
www.sw-motech.com

# STÜCKLISTE / PARTS LIST

| Schritt<br>Step | Nr.<br>No.                     | Art.-Nr. / Bezeichnung *<br>Item No. / Description * | Artikel                    | Part                 | Anzahl **<br>Quantity ** | N·m *** |     |     |      |                                |                               |    |     |     |     |     |     |
|-----------------|--------------------------------|------------------------------------------------------|----------------------------|----------------------|--------------------------|---------|-----|-----|------|--------------------------------|-------------------------------|----|-----|-----|-----|-----|-----|
| 1               | (1)                            | KFT.22.892.003                                       | Querverbinder              | Crossbar             | 1 /1                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (2)                            | M6 x 35; DIN 912                                     | Innensechskantschraube     | Hexagon Socket Screw | 2 /2                     | 8       |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (3)                            | ø 6,4; DIN 9021                                      | Unterlegscheibe            | Washer               | 2 /2                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (4)                            | Ø 14 / ø 8,2 / h 8                                   | Distanzbuchse              | Spacer               | 2 /2                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (5)                            | Ø 15 / ø 6,4 / h 20                                  | Distanzbuchse              | Spacer               | 2 /2                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (6)                            | KFT.22.892.002L                                      | Befestigungslasche; links  | Mounting Tab; left   | 1 /1                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (7)                            | M6 x 25; DIN 912                                     | Innensechskantschraube     | Hexagon Socket Screw | 2 /2                     | 8       |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (8)                            | ø 6,4; DIN 125                                       | Unterlegscheibe            | Washer               | 2 /4                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (9)                            | Ø 14 / ø 6,2 / h 5                                   | Distanzbuchse              | Spacer               | 2 /3                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (10)                           | KFT.22.892.001                                       | Befestigungslasche         | Mounting Tab         | 1 /2                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (11)                           | M8 x 55; DIN 912                                     | Innensechskantschraube     | Hexagon Socket Screw | 1 /1                     | 20      |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (12)                           | ø 8,4; DIN 125                                       | Unterlegscheibe            | Washer               | 1 /1                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (13)                           | Ø 13 / ø 8,4 / h 13                                  | Distanzbuchse; schwarz     | Spacer; black        | 1 /1                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
| 2               | (14)                           | KFT.22.892.002R                                      | Befestigungslasche; rechts | Mounting Tab; right  | 1 /1                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (15)                           | M6 x 65; DIN 912                                     | Innensechskantschraube     | Hexagon Socket Screw | 2 /2                     | 8       |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (16)                           | ø 6,4; DIN 125                                       | Unterlegscheibe            | Washer               | 2 /4                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (17)                           | ø 18 / ø 6,4 / h 45                                  | Distanzbuchse; schwarz     | Spacer; black        | 2 /2                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (18)                           | KFT.22.892.001                                       | Befestigungslasche         | Mounting Tab         | 1 /2                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (19)                           | M8 x 40; DIN 912                                     | Innensechskantschraube     | Hexagon Socket Screw | 2 /2                     | 20      |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (20)                           | Ø 18 / ø 8,4 / h 5                                   | Distanzbuchse              | Spacer               | 1 /1                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (21)                           | M8 x 45; DIN 912                                     | Innensechskantschraube     | Hexagon Socket Screw | 1 /1                     | 20      |     |     |      |                                |                               |    |     |     |     |     |     |
|                 | (22)                           | Ø 30 / ø 8,4 / h 5                                   | Distanzbuchse              | Spacer               | 1 /1                     |         |     |     |      |                                |                               |    |     |     |     |     |     |
| 8.8             | Regelgewinde / Coarse Thread Ø |                                                      | M4                         | M5                   | M6                       | M8      | M10 | M12 | 10.9 | Regelgewinde / Coarse Thread Ø |                               | M4 | M5  | M6  | M8  | M10 | M12 |
|                 | Stahl FK 8.8 / Steel CL 8.8    |                                                      | N·m                        | 2,8                  | 5,5                      | 9,6     | 23  | 46  |      | 79                             | Stahl FK 10.9 / Steel CL 10.9 |    | N·m | 4,1 | 8,1 | 14  | 34  |

\* Alle Maßangaben in Millimeter. - \*\* Der zweite Wert gibt die Gesamtanzahl des jew. Artikels in der Lieferung an.  
 \*\*\* **Keine Anzugsmomentvorgabe: Verwenden Sie das vom Fzg.-Hersteller definierte Anzugsmoment!** Das Standard-Anzugsmoment der Tabelle kann verwendet werden, wenn es den Fzg.-Hersteller-Vorgaben entspricht.

\* All measurements in millimeters. - \*\* The second number indicates the total quantity of the part in the delivery.  
 \*\*\* **No torque specifications: Use the torque defined by vehicle manufacturer!** The standard torque in this table can be used as long as it is within the vehicle manufacturer's specifications.




# STÜCKLISTE / PARTS LIST


| Schritt<br>Step | Nr.<br>No. | Art.-Nr. / Bezeichnung *<br>Item No. / Description * | Artikel                                 | Part                            | Anzahl **<br>Quantity ** | N-m *** |
|-----------------|------------|------------------------------------------------------|-----------------------------------------|---------------------------------|--------------------------|---------|
| 3               | [23]       | KFT.22.892.004                                       | Querverbinder                           | Crossbar                        | 1 / 1                    |         |
|                 | [24]       | M6 x 25; ISO 7380                                    | Linsenkopfschraube; schwarz             | Lenshead Screw; black           | 3 / 3                    | 8       |
|                 | [25]       | Ø 14 / ø 6,2 / h 5                                   | Distanzbuchse                           | Spacer                          | 1 / 3                    |         |
| 4               | [26]       | KFT.22.114.971.01 / 972.01                           | Seitenträger; links / rechts            | Side Carrier; left / right      | 2 / 2                    |         |
|                 | [27]       | KFT.22.114.001                                       | Hitzeschutzblech                        | Heat Protection Plate           | 1 / 1                    |         |
|                 | [28]       | KFT.22.114.002                                       | Sechskantbuchse                         | Hexagon Spacer                  | 2 / 2                    |         |
|                 | [29]       | SV.ST.095.501.LK.02                                  | Schnellverschluss mit Sicherungsscheibe | Quick Fastener with Lock Washer | 8 / 8                    |         |
|                 |            |                                                      |                                         |                                 |                          |         |
|                 |            |                                                      |                                         |                                 |                          |         |
|                 |            |                                                      |                                         |                                 |                          |         |
|                 |            |                                                      |                                         |                                 |                          |         |
|                 |            |                                                      |                                         |                                 |                          |         |
|                 |            |                                                      |                                         |                                 |                          |         |
|                 |            |                                                      |                                         |                                 |                          |         |
|                 |            |                                                      |                                         |                                 |                          |         |

|      |                                   |     |     |     |    |     |     |
|------|-----------------------------------|-----|-----|-----|----|-----|-----|
| 8.8  | Regelgewinde / Coarse Thread Ø    | M4  | M5  | M6  | M8 | M10 | M12 |
|      | Stahl FK 8.8 / Steel CL 8.8 N-m   | 2,8 | 5,5 | 9,6 | 23 | 46  | 79  |
| 10.9 | Regelgewinde / Coarse Thread Ø    | M4  | M5  | M6  | M8 | M10 | M12 |
|      | Stahl FK 10.9 / Steel CL 10.9 N-m | 4,1 | 8,1 | 14  | 34 | 67  | 115 |

\* Alle Maßangaben in Millimeter. - \*\* Der zweite Wert gibt die Gesamtanzahl des jew. Artikels in der Lieferung an.  
 \*\*\* **Keine Anzugsmomentvorgabe: Verwenden Sie das vom Fzg.-Hersteller definierte Anzugsmoment!** Das Standard-Anzugsmoment der Tabelle kann verwendet werden, wenn es den Fzg.-Hersteller-Vorgaben entspricht.

\* All measurements in millimeters. - \*\* The second number indicates the total quantity of the part in the delivery.  
 \*\*\* **No torque specifications: Use the torque defined by vehicle manufacturer!** The standard torque in this table can be used as long as it is within the vehicle manufacturer's specifications.





Verschrauben Sie den Querverbin-  
der (1) am Fahrzeug, wie in der  
Zeichnung gezeigt.

**ACHTUNG: Verwenden Sie bei  
Modellen ab 2017 Distanzbuchse  
(5) statt (4)!**

**ACHTUNG: Verwenden Sie flüssige  
Schraubensicherung!**

Ziehen Sie die Schrauben noch nicht  
an.

Entfernen Sie die gezeigte Schraube  
und die Kunststoffkappen von der  
**linken** Sozialsfußraste.

Verschrauben Sie nun die  
Befestigungslaschen (6) und (10) an  
der Sozialsfußraste, wie in der  
Zeichnung gezeigt.

**ACHTUNG: Verwenden Sie flüssige  
Schraubensicherung!**

Ziehen Sie die Schrauben noch nicht  
an.

Attach the crossbar (1) to the  
vehicle, as shown in the drawing.

**ATTENTION: For models from 2017  
onwards use spacer (5) instead of  
(4).**

**ATTENTION: Use liquid thread  
locker!**


Do not fully tighten the screws yet.

Remove the shown plastic caps and  
screw from the **left** passenger  
footrest.

Attach the mounting lugs (6) and  
(10) to the passenger footrest, as  
shown in the drawing.

**ATTENTION: Use liquid thread  
locker!**

Do not fully tighten the screws yet.



Entfernen Sie die gezeigten  
Schrauben und Kunststoffkappen  
von der **rechten** Sozialsfußraste und  
dem Auspuffhalteblech.

Verschrauben Sie nun die  
Befestigungslaschen (14) und (18)  
an bzw. hinter der Sozialsfußraste,  
wie in der Zeichnung gezeigt.

**ACHTUNG: Verwenden Sie flüssige  
Schraubensicherung!**

Ziehen Sie die Schrauben noch nicht  
an.



Remove the shown plastic caps and  
screws from the **right** passenger  
footrest and the exhaust mount.

Attach the mounting lugs (14) and  
(18) to and behind the passenger  
footrest, as shown in the drawing.

**ATTENTION: Use liquid thread  
locker!**

Do not fully tighten the screws yet.

3



Entfernen Sie den Nummernschildhalter vom Fahrzeug.

Verschrauben Sie den Querverbin-  
der (23) zwischen Kotflügel und  
dem Nummernschildhalter, wie in  
der Zeichnung gezeigt.

**ACHTUNG: Verwenden Sie flüssige  
Schraubensicherung!**

Ziehen Sie die Schrauben noch nicht  
an.


Remove the license plate mount.

Attach the crossbar (23) between  
mudguard and license plate mount,  
as shown in the drawing.

**ATTENTION: Use liquid thread  
locker!**

Do not fully tighten the screws yet.

4




Verschrauben Sie das Hitzeschutz-  
blech (27) mit den Teilen Ihres  
Adapterkit am rechten Seitenträger  
(26), wie in der Zeichnung gezeigt  
(Beispielabbildung; die Teile  
variieren je nach Adapterkit).

**ACHTUNG: Verwenden Sie flüssige  
Schraubensicherung!**


Attach the heat protection plate (27)  
with the parts of your adapter kit to  
the side carrier (26), as shown in  
the detail drawing (example  
drawing; the parts vary depending  
on the adapter kit).

**ATTENTION: Use liquid thread  
locker!**

5



Diebstahlsicherung hier einsetzen.  
Insert the Anti-Theft Device here.



**ACHTUNG: Demontieren Sie die Seitenträger (26) bei Fahrten ohne Gepäck!**

Verbinden Sie die Seitenträger (26) mit den Schnellverschlüssen (29) an den Querverbindern und Befestigungslaschen. Sichern Sie die Schnellverschlüsse mit den Sicherungsscheiben.

Wenn alle Komponenten spannungsfrei sitzen, ziehen Sie die Schrauben wie vorgegeben an.

*HINWEIS: Die Diebstahlsicherung ist separat erhältlich.*

**ATTENTION: Dismount the side carriers (26) when travelling without sidcases!**

Use the fasteners (29) to connect the side carriers (26) to the crossbars and mounting lugs. Secure the fasteners with the lock washers.

Once all the parts are evenly positioned without excess tension, tighten the screws as specified.

*NOTE: The Anti-Theft Device is sold separately.*

|    |  |  |        |
|----|--|--|--------|
| 15 |  |  | 8 N·m  |
| 21 |  |  |        |
| 24 |  |  |        |
| 2  |  |  | 20 N·m |
| 7  |  |  |        |
| 11 |  |  |        |
| 19 |  |  |        |

Item number: KFT.00.152.36000

Revision: 00 • Date: 08 - 2023

## Adapter kit for PRO side carrier

 ~ 0.25 h.EASY      DIFFICULT

**ENGLISH** Thank you for choosing this premium product from SW-MOTECH. Visit our online shop for more information (e.g. model assignments). Required documents (e.g. national type approval) are available there for you to download.

Please read and understand all the instructions, safety information and warnings in these mounting instructions before mounting and using the product in order to avoid injury and damage. Keep these mounting instructions for reference.

This product was developed for vehicles in factory condition. Compatibility with original accessories or accessories from other manufacturers cannot be guaranteed.

These mounting instructions have been prepared to the best of our current knowledge. No legal claims relating to accuracy can be made. Errors and omissions excepted. We reserve the right to make technical and design changes. The copyright is held by SW-MOTECH.

## SAFETY WARNING SYMBOL

 This warning symbol is used in these mounting instructions to warn of deadly dangers, injuries or other hazards. The words DANGER, WARNING or CAUTION are used as part of this warning symbol to convey important safety messages and information relating to the installation and use of this product. These words, together with the safety warning symbol, mean:

 **DANGER:** Indicates a hazardous situation which, if not avoided, will result in death or serious injury!

 **WARNING:** Indicates a hazardous situation which, if not avoided, may result in death or serious injury!

 **CAUTION:** Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury!

 **NOTE:** Important information, but not relating to a risk of death or injury (property damage only)!

## GENERAL INFORMATION

 **WARNING:** Assembly and/or maintenance of this product requires advanced technical skill, appropriate tools, and a good understanding of tool usage and torque specifications. For your own safety, SW-MOTECH recommends having the assembly and/or maintenance carried out by a qualified and certified motorcycle workshop.

 **WARNING:** If you do choose to assemble this product yourself, carefully and fully read the mounting instructions before assembly and use, and follow all instructions to avoid serious injury or death. Also observe all relevant information in the vehicle manual when mounting or using the product. IF YOU DO NOT UNDERSTAND ANY PART OF THESE MOUNTING INSTRUCTIONS OR NEED AN EXPLANATION AS TO A SPECIFIC INSTRUCTION, DO NOT ATTEMPT TO INSTALL THIS PRODUCT WITHOUT CONSULTING SW-MOTECH FOR ASSISTANCE!

**PREPARATION:** Read the mounting instructions carefully and make sure that all parts on the parts list are available.

 **CAUTION:** Ensure that your vehicle is standing securely. Switch off the engine and remove the ignition key. Allow the engine/exhaust to cool down if necessary. Disconnect the battery when working on the electrical system. Only use proper tools and always wear safety goggles and gloves during assembly and maintenance. Have a second person help you with assembly and maintenance.

**ASSEMBLY:** All parts and connections removed from the vehicle must be reinstalled according to the vehicle manufacturer's specifications or replaced with parts and hardware supplied by SW-MOTECH.

 **WARNING:** Secure all threads with a medium-strength liquid threadlocker, unless otherwise specified.

 **DANGER:** Tightening torques not defined by SW-MOTECH must be obtained from the vehicle manufacturer or a certified motorbike workshop.

**FUNCTIONAL CHECK:** After mounting the product, ensure that no moving parts are obstructed and that the function of the vehicle is not impeded. Cables and hoses must not rub against each other and/or be hindered in any way.

 **WARNING:** Carry out a comprehensive functionality check before you start to drive. Check the tightening torque of all connections and the tight fit of the product after the first 50 km and then at regular intervals. Mounted accessories can change the handling and stability of the vehicle.



SW-MOTECH GmbH & Co. KG  
Ernteweg 7-10  
35282 Rauschenberg  
Germany



info@sw-motech.com  
www.sw-motech.com



Take note of the symbols and what they mean in the ASSEMBLY section. If the term OEM appears in the ASSEMBLY section, the vehicle manufacturer's specifications must be observed and applied.



If you have any questions, please don't hesitate to contact our Customer Service team or our distributors. You can find our telephone number and a list of our distributors in our online shop:

**[www.sw-motech.com](http://www.sw-motech.com)**



**Do not use thread lock:** Indicates that no liquid thread lock should be used at this point.



**Tighten/note the tightening torque information:**

Indicates the tightening torque of a part specified by SW-MOTECH or the vehicle manufacturer (OEM).




**Use thread locker:** Indicates that a thread must be coated with liquid thread locker. H (HIGH): high strength; M (MEDIUM): medium strength; L (LOW): low strength.

**PARTS LIST • READ AND KEEP MOUNTING INSTRUCTIONS!**

|          |                                                                                                                                                                                                                                                                                                                                    |
|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>1</b> | <div data-bbox="151 147 359 369"></div> <div data-bbox="151 369 359 456"><div>HSK.00.745.025.35GR</div><div> <b>2/2</b></div></div>                              |
| <b>2</b> | <div data-bbox="375 147 582 369"></div> <div data-bbox="375 369 582 456"><div>M6 x 12; ISO 7380<br/>SC.ST.06.012.02.7380.109</div><div> <b>4/4</b></div></div>   |
| <b>3</b> | <div data-bbox="598 147 805 369"></div> <div data-bbox="598 369 805 456"><div>GPT.00.152.010.35</div><div> <b>4/4</b></div></div>                                |
| <b>4</b> | <div data-bbox="821 147 1029 369"></div> <div data-bbox="821 369 1029 456"><div>M6 x 25; DIN 7991<br/>SC.ST.06.025.02.7991.088</div><div> <b>4/4</b></div></div> |
| <b>5</b> | <div data-bbox="1045 147 1252 369"></div> <div data-bbox="1045 369 1252 456"><div>M6; DIN 6927<br/>MU.ST.06.02.6927.08</div><div> <b>4/4</b></div></div>     |
| <b>6</b> | <div data-bbox="1268 147 1476 369"></div> <div data-bbox="1268 369 1476 456"><div>KFT.00.152.026.02</div><div> <b>8/8</b></div></div>                        |

1





**⚠ WARNING:** Always wear eye and hand protection!  
**⚠ WARNING:** Always use the proper tools!

**⚠ NOTE:** The illustration shows how to mount on the right PRO side carrier.  
 Follow the same steps with the left PRO side carrier as with the right PRO side carrier.

Screw the parts indicated to your PRO side carriers (sold separately).

**⚠ ATTENTION:** Use liquid thread locker (screws (2) only)!  
 Tighten the screws as specified in the mounting instructions.

Then insert the rubber dampeners (6) into the indicated openings.



**PRODUCT-SPECIFIC NOTES**

**⚠ NOTE:** *Observe the country-specific regulations for the registration/operation of your vehicle or applicable TÜV regulations. After assembly, have parts that are subject to registration entered in the vehicle documents by your test centre.*

Item number: **LOC.00.745.10200**Revision: **00** • Date: **08 - 2023****Hard case lock set** ~ 0.25 h.EASY      DIFFICULT

**ENGLISH** Thank you for choosing this premium product from SW-MOTECH. Visit our online shop for more information (e.g. model assignments). Required documents (e.g. national type approval) are available there for you to download.

Please read and understand all the instructions, safety information and warnings in these mounting instructions before mounting and using the product in order to avoid injury and damage. Keep these mounting instructions for reference.

This product was developed for vehicles in factory condition. Compatibility with original accessories or accessories from other manufacturers cannot be guaranteed.

These mounting instructions have been prepared to the best of our current knowledge. No legal claims relating to accuracy can be made. Errors and omissions excepted. We reserve the right to make technical and design changes. The copyright is held by SW-MOTECH.

**SAFETY WARNING SYMBOL**

 This warning symbol is used in these mounting instructions to warn of deadly dangers, injuries or other hazards. The words **DANGER**, **WARNING** or **CAUTION** are used as part of this warning symbol to convey important safety messages and information relating to the installation and use of this product. These words, together with the safety warning symbol, mean:

 **DANGER:** Indicates a hazardous situation which, if not avoided, will result in death or serious injury!

 **WARNING:** Indicates a hazardous situation which, if not avoided, may result in death or serious injury!

 **CAUTION:** Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury!

 **NOTE:** Important information, but not relating to a risk of death or injury (property damage only)!

**GENERAL INFORMATION**

 **WARNING:** Assembly and/or maintenance of this product requires advanced technical skill, appropriate tools, and a good understanding of tool usage and torque specifications. For your own safety, SW-MOTECH recommends having the assembly and/or maintenance carried out by a qualified and certified motorcycle workshop.

 **WARNING:** If you do choose to assemble this product yourself, carefully and fully read the mounting instructions before assembly and use, and follow all instructions to avoid serious injury or death. Also observe all relevant information in the vehicle manual when mounting or using the product. IF YOU DO NOT UNDERSTAND ANY PART OF THESE MOUNTING INSTRUCTIONS OR NEED AN EXPLANATION AS TO A SPECIFIC INSTRUCTION, DO NOT ATTEMPT TO INSTALL THIS PRODUCT WITHOUT CONSULTING SW-MOTECH FOR ASSISTANCE!

**PREPARATION:** Read the mounting instructions carefully and make sure that all parts on the parts list are available.

 **CAUTION:** Ensure that your vehicle is standing securely. Switch off the engine and remove the ignition key. Allow the engine/exhaust to cool down if necessary. Disconnect the battery when working on the electrical system. Only use proper tools and always wear safety goggles and gloves during assembly and maintenance. Have a second person help you with assembly and maintenance.

**ASSEMBLY:** All parts and connections removed from the vehicle must be reinstalled according to the vehicle manufacturer's specifications or replaced with parts and hardware supplied by SW-MOTECH.

 **WARNING:** Secure all threads with a medium-strength liquid threadlocker, unless otherwise specified.

 **DANGER:** Tightening torques not defined by SW-MOTECH must be obtained from the vehicle manufacturer or a certified motorbike workshop.

**FUNCTIONAL CHECK:** After mounting the product, ensure that no moving parts are obstructed and that the function of the vehicle is not impeded. Cables and hoses must not rub against each other and/or be hindered in any way.

 **WARNING:** Carry out a comprehensive functionality check before you start to drive. Check the tightening torque of all connections and the tight fit of the product after the first 50 km and then at regular intervals. Mounted accessories can change the handling and stability of the vehicle.



SW-MOTECH GmbH & Co. KG  
Ernteweg 7-10  
35282 Rauschenberg  
Germany



 [info@sw-motech.com](mailto:info@sw-motech.com)  
 [www.sw-motech.com](http://www.sw-motech.com)



Take note of the symbols and what they mean in the ASSEMBLY section. If the term OEM appears in the ASSEMBLY section, the vehicle manufacturer's specifications must be observed and applied.



If you have any questions, please don't hesitate to contact our Customer Service team or our distributors. You can find our telephone number and a list of our distributors in our online shop:

**[www.sw-motech.com](http://www.sw-motech.com)**

PARTS LIST • READ AND KEEP MOUNTING INSTRUCTIONS!

2

|                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                      |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div>1</div> <div></div> <div>HSK.00.745.500.04</div> <div> 3/3</div> | <div>2</div> <div></div> <div>T20<br/>TRX.T20</div> <div> 1/1</div> | <div>3</div> <div></div> <div>ALK.00.165.A63</div> <div> 2/2</div> |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|


3

|                                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div>3</div> <div></div> <div>ALK.00.165.562.01</div> <div> 1/1</div> |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

4

|                                                                                                                                                                                                                                           |                                                                                                                                                                                                                                             |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div>5</div> <div></div> <div>QLS.00.095.520.01</div> <div> 2/2</div> | <div>6</div> <div></div> <div>SV.ST.095.007.LK.02</div> <div> 2/2</div> |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

1



⚠ **WARNING:** Always wear eye and hand protection!

⚠ **WARNING:** Always use the proper tools!




#### Opening the lid

**1.1** - Press the DUSC release button (\*) and pull the lid latch buckle into the open position.

**1.2** - Remove the latch buckle from the corresponding bracket and open the lid.



2



#### Install DUSC lock

**2.1** - Open the DUSC (\*) latch buckle and position the lock (1) as shown.

**⚠ NOTE: DUSC L ONLY:** Make sure the locking tab (highlighted in red) is in the unlocked position (up)! If necessary, the locking tab must be pushed up into the unlocked position!


**2.2** - Push the lock (1) down until it clicks into place.


**2.3** - Screw in the lock (1) using the screws (\*) supplied with the DUSC and the torx key (2). Carefully tighten the screws by hand.

**⚠ WARNING: Over-tightening the screws may damage the lock casing!**

**⚠ NOTE:** Ensure that the locking mechanism is in working order!

**⚠ NOTE:** NEVER lubricate the lock cylinder with oil! Only use graphite powder!




**3****Install toolbox lock**

**3.1** - Insert the lock (4) with the sealing ring (\*) supplied with the toolbox in the lock hole of the cover. Secure the lock (4) on the inside with the safety clip (4)

**⚠ NOTE:** NEVER lubricate the lock cylinder with oil! Only use graphite powder!



4



#### Mount anti-theft protection device for PRO side carrier

**4.1** - Insert the anti-theft protection device (5) into the side carrier opening defined in the side carrier mounting instructions. Secure the anti-theft protection device (5) with the lock washer (6).

**4.2** - Now insert the anti-theft protection device (5) in the opening of the side support fastener ...

**4.3** - ... and turn the anti-theft protection device (5) until it engages.

**4.4** - Then the anti-theft protection device (5) must be secured against unscrewing.

**⚠ NOTE:** NEVER lubricate the lock cylinder with oil! Only use graphite powder!



**PRODUCT-SPECIFIC NOTES**

**⚠ NOTE:** *Observe the country-specific regulations for the registration/operation of your vehicle or applicable TÜV regulations. After assembly, have parts that are subject to registration entered in the vehicle documents by your test centre.*