



FITTING INSTRUCTIONS FOR CP0197 CRASH PROTECTORS YAMAHA R1 2007 UPPERS



One x M10x70mm long cap-head

Two x M6x45mm long cap-head bolts

One x M6x45mm long cap-head bolt

One x M8x50mm long cap-head bolt



LEFT-HAND SIDE

One x M10x60mm long cap-head

One x M6x60mm long cap-head bolt

One x M6x55mm long cap-head bolt




RIGHT-HAND SIDE

One x M6x35mm long cap-head bolt



TOWARDS REAR
OF BIKE



TOWARDS FRONT
OF BIKE



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

TOOLS REQUIRED

- Set of metric Allen keys to include 5, 6 and 8mm.
- Socket set to include 17 and 19mm sockets and wrench.
- Torque wrench (up to 40Nm)

Left-hand side (as you sit on bike)

- Remove fairing
- Remove the engine bolt labelled one x M10 x 70mm long cap-head on left-hand side picture, do not remove any spacers only the bolt.
- Remove the bolts in positions shown in left-hand side picture.
- Place the appropriate cap-head bolts into holes as labelled in left-hand side picture.
- Offer the mounting block into position engage all bolts before tightening evenly to the manufactures recommended torques.
- Install the M12 x 60mm long Hex-head bolt (with plain washer against head and star shaped lock washer against plain washer) through crash protector and into bobbin spigot and tighten bolt until you feel some compression from inside the protector. **PLEASE NOTE BOBBIN MUST BE POSITIONED AS PICTURED ABOVE WITH BIGGER END TOWARD FRONT OF BIKE.** Turn a little more so that you feel the compression increase slightly. Then apply a quarter turn. Do not over tighten as damage can occur to the bike. Do not exceed 40nm of torque.
- Replace fairing ensuring to connect indicator. Insert bobbin cap so logo is as shown above.

R&G Racing

Unit 5K, Blacknest Industrial Park, Blacknest Road, Alton, Hampshire, GU34 4PX

Tel: +44 (0)870 220 6380 Fax: +44 (0)1420 521101 www.rg-racing.com Email: info@rg-racing.com



Right-hand side (as you sit on bike)

- Remove fairing.
- Remove the engine bolt labelled one x M10 x 60mm long cap-head on right-hand side picture, do not remove any spacers only the bolt.
- Remove the bolts in positions shown in right-hand side picture.
- Place the appropriate cap-head bolts into holes as labelled in right-hand side picture.
- Offer the mounting block into position engage all bolts before tightening evenly to the manufactures recommended torques.
- Install the M12 x 60mm long Hex-head bolt (with plain washer against head and star shaped lock washer against plain washer) through crash protector and into bobbin spigot and tighten bolt until you feel some compression from inside the protector. **PLEASE NOTE BOBBIN MUST BE POSITIONED AS PICTURED ABOVE WITH BIGGER END TOWARD FRONT OF BIKE.** Turn a little more so that you feel the compression increase slightly. Then apply a quarter turn. Do not over tighten as damage can occur to the bike. Do not exceed 40nm of torque.
- Replace fairing ensuring to connect indicator. Insert bobbin cap so logo is as shown above.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorised (if not pre-authorised the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in res-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 5K, Blacknest Industrial Park, Blacknest Road, Alton, Hampshire, GU34 4PX

Tel: +44 (0)870 220 6380 Fax: +44 (0)1420 521101 www.rg-racing.com Email: info@rg-racing.com



FRANCE
INSTRUCTIONS DE MONTAGE DES PROTECTIONS
CP0197
YAMAHA R1 2007 Position haute

LA PRESENTATION DES PIECES R&G DANS L'EMBALLAGE N'EST PAS TOUJOURS IDENTIQUE AU SENS DE MONTAGE.

Merci de noter que dans le cas où les protections sont assemblées avec une bague en caoutchouc, merci de bien vouloir le retirer lors du montage des pièces sur la moto.

Outils nécessaires

- Jeu de clé Allen 5,6 and 8mm.
- Jeu de clé 17 et 19mm.
- Clé dynamométrique (40Nm)

Gauche (left hand side)

- Enlever le carénage.
- Enlever la vis de fixation moteur M10x70mm (photo en haut à gauche). N'enlever que la vis par les entretoises.
- Enlever les autres vis indiquées sur la photo (left hand side).
- Placer les vis fournies dans le kit dans le bloc en aluminium (voir photo left hand side).
- Placer le bloc et les vis sur la moto et engager les vis dans les trous de fixation. Serrer au couple de serrage préconisé par le fabricant.
- Glisser une rondelle lisse et puis une rondelle crantée sur la vis M12x60mm.
- Passer le tout à travers un tampon R&G, et fixer le tout sur le bloc (vis central)
- Attention au sens de montage des protections (la partie la plus large vers l'avant de la moto).
- Serrer la vis jusqu'à ce que vous sentiez la compression à l'intérieur du tampon, Faire encore un quart de tours.

Ne pas trop serrer, couple de serrage Maxi 40nm

- Remonter le carénage et reconnecter le clignotant.
- Clipper le cache vis (avec le logo R&G) dans le tampon.

Droit (right-hand side)

- Enlever le carénage.
- Enlever la vis de fixation moteur M10x60mm (photo en haut à droite). N'enlever que la vis par les entretoises.
- Enlever les autres vis indiquées sur la photo (right hand side).
- Placer les vis fournies dans le kit dans le bloc en aluminium (voir photo right hand side).
- Placer le bloc et les vis sur la moto et engager les vis dans les trous de fixation. Serrer au couple de serrage préconisé par le fabricant.
- Glisser une rondelle lisse et puis une rondelle crantée sur la vis M12x60mm.
- Passer le tout à travers un tampon R&G, et fixer le tout sur le bloc (vis central)
- Attention au sens de montage des protections (la partie la plus large vers l'avant de la moto).
- Serrer la vis jusqu'à ce que vous sentiez la compression à l'intérieur du tampon, Faire encore un quart de tours.

Ne pas trop serrer, couple de serrage Maxi 40nm

- Remonter le carénage et reconnecter le clignotant.
- Clipper le cache vis (avec le logo R&G) dans le tampon.